

ME 566
Computational Fluid Dynamics for Fluids Engineering
Design
ANSYS CFX STUDENT USER MANUAL Version 11

Gordon D. Stublely
Department of Mechanical Engineering, University of Waterloo
©G.D. Stublely 2008

April 30, 2009

Contents

Contents	i
Preface	iii
I Tutorial	1
1 Overview of CFD Process	2
1.1 Example Problem	2
1.2 Domain	2
1.3 Domain Descritization: Mesh	3
1.4 CFD Flow Solver	4
1.5 Post-processing	8
2 Tutorial Commands	10
2.1 Introduction to the GUI	10
2.2 Commands for Duct Bend Example	13
II Additional Notes	30
3 Geometry and Mesh Specification	31
3.1 Basic Geometry Concepts and Definitions	31
3.2 Geometry Creation	32
3.3 Mesh Generation	34
4 CFX-Pre: Physical Modelling	42
4.1 Domain	43
4.2 Initialization	46
4.3 Output Control	47
4.4 Simulation Type	47
4.5 Solver Control	47
5 CFX Solver Manager: Solver Operation	49
5.1 Monitoring the Solver Run	49

6	CFX-Post: Visualization and Analysis of Results	52
6.1	Conventions	52
6.2	Objects	54
6.3	Tools	55
6.4	Controls	56
7	Frequently Asked Questions	57
7.1	Where are the ANSYS-CFX tutorial files?	57
7.2	How to use an existing mesh after modifying the geometry?	57
7.3	How to use an existing CFX-Pre model after modifying the mesh?	57
7.4	How is heat conduction modelled in a single domain?	57
7.5	Why is there only a few point values given when exporting data along a line normal to a wall?	58
7.6	How is a thin guide vane modelled?	58

Preface

In these notes the basic steps in a CFD solution will be illustrated using the professional software ANSYS Workbench Version 11 which includes the components DesignModeler, Meshing, and Advanced CFD (all trademarks of ANSYS). These notes include an introductory tutorial and a mini user's guide. In particular, the notes are pertinent to the simulation of two dimensional steady incompressible laminar and turbulent fluid flows on stationary meshes. They are not meant to replace a detailed user's guide. For full information on these components refer to the on-line help documentation provided with the software ¹.

These notes include sections on:

Overview of CFD Simulation An introductory section outlining the components of a CFD simulation. Includes the description of an example CFD analysis problem;

Commands for the Example Problem: A complete step-by-step list of instructions for solving the example problem.

Software Components: A description of the concepts and operation involved in the five software components: DesignModeler, Meshing, CFX-Pre, CFX-Solver, and CFX-Post; and

Frequently Asked Questions: Suggestions for further study and for solving typical flow cases.

The following font/format conventions are used to indicate the various commands that should be invoked:

Menu/Sub-Menu/Sub-Sub-Menu Item chosen from the menu hierarchy at the top of a main panel or window,

Button/Tab Command Option activated by clicking on a button or tab,

Link description Click on the description to move by a link to the next step/page;

Name Enter the *value* in the named box,

¹Many of the features available in these software components will not be explored in introductory CFD courses.

Name ▼ Choose the selection(s) from the named list,

Name Panel or window name,

Name On/off switch box, and

Name On/off switch circle (radio button).

Part I
Tutorial

Chapter 1

Overview of CFD Process

1.1 Example Problem

To provide a context for these notes consider the application of CFD to studying the flow in a short radius bend within the duct system shown in Figure 1.1. There is a flow of water upwards into the bend.

The side view of the duct bend geometry is shown in Figure 1.2. The radius of the inner wall bend is $R1 = 0.025[m]$. The spacing between the duct inner wall and outer wall is $H3 = 0.1[m]$. The duct has a width (into the page) of $1[m]$. The average speed of the water flow through the duct is $3[m/s]$.

The purpose of the CFD analysis is to determine if and where flow separation is an issue. CFD is well suited to this task because it can provide a detailed representation of the velocity and pressure fields throughout the flow domain. By examining the velocity field it will be possible to identify regions where the flow separates and reverses direction and by examining the pressure field it will be possible to identify regions where flow reversal is likely to occur. In this chapter a brief description of how these field properties are determined is presented.

1.2 Domain

The CFD simulation is restricted to a specific three dimensional region known as the *domain*. For the duct bend example, the domain, shown in Figures 1.1 and 1.2, is a thin volume that is bounded by the outer wall, the inner wall, by planes perpendicular to the flow upstream and downstream of the bend, and by surfaces in the $x - y$ plane on the front and back sides. The domain extends $V2 = 0.1[m]$ upstream from the bend and $H4 = 0.25[m]$ downstream from the bend. The domain is $0.02[m]$ wide.

The geometry of the domain is represented in digital form by solid modelling software. The resulting geometric model is known as a *solid* or *solid-body* for historical reasons. The volume of the solid geometric model is the volume where the fluid flow is modelled.




Figure 1.1: Schematic of the region near a short radius bend in a duct system. Water is flowing upwards into the bend and to the right out of the bend. A wireframe representation of the CFD flow domain is also shown.

1.3 Domain Description: Mesh

It is not possible to analytically determine mathematical functions for the variation of velocity and pressure throughout complex domains. Therefore approximate values of the velocity components, $U_i, i = 1, 2, 3$,¹ and pressure, p , are generated only at discrete points or *nodes* throughout the domain. The locations of the nodes are based on a *mesh*. A mesh for the duct bend geometry is shown in Figure 1.3.

The mesh is comprised of a set of relatively simple three dimensional polyhedral *elements*. The example mesh is comprised of hexahedral elements. For all meshes, the set of elements is non-overlapping, fills the domain, and fits the boundaries of the domain. For CFX meshes, the nodes are located at the vertices of the elements. The example mesh is only one element thick in the z direction and the surface meshes on the front and back surfaces are identical. This is suitable for this flow because there is no significant variation of flow properties in the z direction.

¹Index notation is used in these notes, where the x, y , and z directions are indicated by indices 1, 2, and 3 respectively.




Figure 1.2: Solid body model of the duct bend geometry included in the CFD flow domain.

1.4 CFD Flow Solver

CFD software assumes that each node is surrounded by a finite control volume bounded by planar faces as illustrated in Figure 1.3. By applying the principles of conservation of momentum and mass to each control volume, a set of finite volume equations are formed which can be solved to provide nodal values of velocity and pressure.

After a mesh has been generated, there are three major steps to create a simulation of the velocity and pressure fields on the mesh:

Flow Model Specification: identify all significant flow processes (such as advective flows and stress tensor forces) and their appropriate models;

Finite Volume Equation Generation: apply a set of numerical approximations to estimate all control volume flow processes in terms of the nodal field property values. When applied to the conservation principles, this leads to a set of finite volume equations; and

Finite Volume Equation Solution: use a nonlinear matrix solution algorithm to solve the equation set for estimates of the nodal values of velocity and pressure.




Figure 1.3: Mesh of hexahedral elements for the duct bend geometry showing a typical node and finite control volume.

By convention the software that performs these three steps is referred to as the *CFD flow solver*.

Flow Model Specification

The first step of the CFD flow solver requires input from the CFD analyst to identify the relevant flow processes and to choose suitable models for these processes.

For the example problem of flow through the duct bend:

- **Type of Flow:** the flow is modelled as *turbulent, non-buoyant, steady* in the mean flow properties, and doesn't involve heat transfer;
- **Fluid Type and Properties:** the fluid, water, is modelled as a *constant property Newtonian liquid*, with a density of $\rho = 1000[\text{kg}/\text{m}^3]$ and dynamic viscosity of $\mu = 0.001[\text{Pa} \cdot \text{s}]$;
- **Flow Domain Properties:** the domain is modelled as *stationary*;
- **Turbulence Model:** the mean action of the turbulent eddying motion on the mean velocity field is accounted for with the *k-epsilon* ($k - \epsilon$) model. In

this model, the turbulent Reynolds stresses, $-\overline{\rho u'_i u'_j}$, are related to the mean velocity strain rate by

$$-\overline{\rho u'_i u'_j} \approx \mu_t \left(\frac{\partial U_i}{\partial x_j} + \frac{\partial U_j}{\partial x_i} \right)$$

where the turbulent viscosity, μ_t , is proportional to the fluid density, the velocity scale (intensity) of the turbulent eddies, and the length scale of the eddies. The scales of the turbulent eddying motion are estimated from two field properties of the turbulence which are calculated at each node: k , mean turbulent kinetic energy (i.e. kinetic energy associated with swirling turbulent eddies) and ε , the rate at which k is dissipated by molecular action; and

- **Boundary Conditions:** modelling the influence of the surroundings on the flow domain are specified for each surface on the flow domain and are modelled as:
 - **[Inflow Surface:]** with a uniform normal velocity of $V_{in} = 3[m/s]$, turbulent intensity, $I \equiv \frac{\sqrt{k}}{V_{in}} = 5\%$, and turbulent length scale, $l \equiv \frac{k^{\frac{3}{2}}}{\varepsilon} = 0.01[m]$;
 - **[Outflow Surface:]** with a uniform relative pressure of $0[Pa]$;
 - **[Inner and Outer Walls:]** modelled as smooth no-slip walls. The turbulent wall shear stress is estimated with the Law of the Wall for equilibrium turbulent boundary layers;
 - **[Front and Back Surfaces:]** modelled as symmetry surfaces implying no mass flow across these surfaces and all normal gradients are zero.

Finite Volume Equation Generation

As mentioned above, a finite control volume surrounds each node in the mesh. Once calculated the nodal field values are representative average values for their respective control volumes. To calculate the nodal field values a set of discrete algebraic equations based upon conservation principles are formed. For the duct bend example, these equations are based on conservation of mass, momentum in 3 directions, x , y , and z , turbulent kinetic energy, and its dissipation rate.

The finite volume methodology can be illustrated with a simplified discussion of the generation of the discrete mass conservation equation. Consider mass conservation for the control volume surrounding the P node shown in Figure 1.3. With the specified steady incompressible flow model, mass conservation implies that the sum of mass flows across the faces of the P control volume must balance or

$$0 = \sum_{\text{faces}} \rho \vec{V}_{\text{face}} \cdot \hat{n} A_{\text{face}} \quad (1.1)$$

where \vec{V}_{face} is the face average velocity, \hat{n} is the face outwards pointing unit normal vector, and A_{face} is the face area. Notice that Equation 1.1 provides a relationship in

terms of face velocities and not one in terms of the nodal velocities. However, each interior face separates two neighbour nodes. If numerical interpolation functions are used to estimate the face velocities in terms of the neighbour nodal values then a useful discrete mass conservation equation can be formed in terms of the nodal values.

Typically the interpolation functions assume some form of linear interpolation. While largely prescribed by the CFD software, the choice of certain interpolation functions can be set by the CFD analyst.

For the duct bend example the following interpolation functions are specified:

Mass flows: linear-linear-linear interpolation;

Diffusive flows: linear-linear-linear interpolation;

Advective flows: upwind weighted linear interpolation based on nodal values and gradient estimates (high resolution scheme)

Pressure forces: linear-linear-linear interpolation; and

Stress tensor forces: linear-linear-linear interpolation.

Finite Volume Equation Solution

For the duct bend example, there are five unknown field properties at each node, pressure, three velocity components, turbulent kinetic energy, and its dissipation rate. As explained above, five corresponding discrete algebraic equations can be generated for each node based on conservation of mass, momentum in three directions, turbulent kinetic energy, and its dissipation rate. Therefore, once finite volume equations are generated for each node there is a set of equations which can be solved to determine estimates of the nodal field properties.

This equation set is highly coupled, both linearly and nonlinearly. Therefore an iterative solution algorithm is implemented in the CFD solver to obtain estimates of the nodal field properties. The essence of the algorithm:

1. Make an initial guess for each field property at each node;
2. Determine the imbalance, *residual*, in each finite volume conservation equation. If the residual imbalance values are sufficiently small stop the iteration. If not continue with the following;
3. Use the residual values to estimate improved values for the nodal field property values;
4. Return to Step 2.




Figure 1.4: Vector plot of the simulated flow field through a duct bend showing separated flow on the inner wall downstream of the bend.

1.5 Post-processing

The CFD flow solver provides estimates of fundamental field properties at each node. Often this information is insufficient. For example, in the duct bend flow it is necessary to know the extent of the possible separated flow regions and the drop in total pressure through the bend. This information is found by post-processing the nodal values to provide graphic images or to calculate secondary values of direct relevance to evaluating the flow.

Figure 1.4 shows a vector plot of the simulated flow through the duct bend. A separated flow region adjacent to the inner wall downstream of the bend is clearly seen. Regions of high speed and low speed flow are also seen in this visualization.

A summary of the complete CFD model including meshing details is shown in Figure 1.5.



Physical Model Details

Water: $\rho = 1000 \text{ [kg/m}^3\text{]}$, $\mu = 0.001 \text{ [Pa s]}$
 k-Epsilon model, scalable wall functions

Numerical Model Details

High Resolution Scheme
 Auto-timescale
 $\delta r_{\text{max}} = 0.001$

Mesh Details

Edge 1: $N = 25$, Bias Factor = 50
 Edge 2: $\Delta = 0.01 \text{ [m]}$, Uniform
 Edge 3: $N = 20$, Uniform
 Edge 4: $\Delta = 0.01 \text{ [m]}$, Bias Factor=5




Figure 1.5: Summary of the CFD model for flow through a duct bend.

Chapter 2

Tutorial Commands

2.1 Introduction to the GUI

Windows XP/NEXUS

The CFD software is available on the workstations in the Engineering Computing labs Wedge (E2-1302B), Pulley (CPH-2367), and the Mechanical Engineering 4th year computing rooms, E3-3111 and E2-2354. See ME 566 course page for up-to-date details on availability. The workstations use the Windows XP operating system on Waterloo NEXUS. You should be familiar with techniques to create new folders (or directories), to delete files, to move through the folder (directory) system with Windows Explorer, to open programs through the Start menu on the Desktop toolbar, to move, resize, and close windows, and to manage disk space usage with tools like WinZip.

Introduction to Workbench

The ANSYS Workbench environment provides an interface to manage the files and databases associated with the individual software components. These files and databases are organized into a particular project. To get a feel for this environment and the GUIs associated with the software components, we will look at a pre-prepared project on flow through a pipe bend.

1. Create a working directory called CFDTest on your N drive.
2. Use a web browser to visit the UW-ACE ME 566 course page (uwace.uwaterloo.ca). Under the Lessons tab and open the Student User Manual folder. Click on the link to PipeBend.zip and follow the instructions to download the archive containing the working files.
3. Use WinZip to extract the files in the PipeBend archive into your working directory.
4. Open ANSYS Workbench from **Start/Programs/ANSYS 11.0/ANSYS Workbench**.

5. Open the project file. Check that **Open:** ▼ **Workbench Project** is selected before using the **Browse** button below the **Open: Workbench Projects** panel area to find and selecting the file PipeBend.wbdb from your working directory.
6. There are three main areas on the screen: command menus, buttons, and tabs at the top, a list of potential Project Tasks on the left, and a list of the files linked to the project.
7. On-line help for Workbench, DesignModeler, and CFX-Mesh is available in web-page format similar to other Windows programs. Choose **Help/ANSYS Workbench Help** to open the ANSYS Workbench Documentation. Search for keyword **Tutorials** and select CFX-Mesh Help. Follow the [Tutorials](#) link to see the list of available tutorials.

Introduction to DesignModeler/CFX-Mesh GUI

1. In the Workbench file area click on the item name PipeBend just to the right of the DesignModeler button (**DM**). Notice that the Project Tasks area at the left adjusts to reflect your choice. Under DesignModeler Tasks choose [Open](#) to open the geometry file.
2. A new page for DesignModeler will open. Go back to the Project page by clicking on the **PipeBend [Project]** tab at the top left of the screen. Click on the **PipeBend [DesignModeler]** tab to return to the DesignModeler page.
3. There are four major areas on the page: command menus and buttons at the top, a Tree View and Sketch Toolbox on the left, a Details View at the bottom left, and a Model View window. Place the mouse cursor over one of the command buttons in the top row. A brief description of the button's action should appear (you may need to click in the window once to make it active). Visit each button with the mouse cursor to see its action.
4. One method of controlling the view is with the coordinate system triad in the lower right corner of Model View. Click on the Z axis of the triad to see a back view of the pipe bend. Click on the cyan sphere to select the isometric view.
5. Another method of controlling the view is with the mouse left button in conjunction with a mouse action selection. From the upper row of buttons, select the **Pan** action. Holding the left mouse button down, drag the mouse over the Model View to translate the view. Select the **Zoom** action and repeat with an up-down mouse action to change the size of the view.
6. Select the **Rotate** action. The rotate action is context sensitive in that it depends upon the position of the mouse cursor. With the mouse cursor close to the pipe bend, press the left mouse button to get *free 3D rotation*. The point

of rotation can be changed by clicking the left button while the cursor is on the pipe bend surface (this may take some experimentation). With the mouse cursor in a corner of the Model View, press and hold the left mouse button to get a *roll* action in which there is 2D rotation about an axis perpendicular to the Model View window. Move the cursor to either the left or right of the Model View and hold the left button to get a *yaw* action in which there is 2D rotation about the vertical axis. Move the cursor to either the top or bottom of the Model View and hold the left button to get a *pitch* action in which there is 2D rotation about the horizontal axis.

7. Rotate, zoom, and pan actions can be achieved directly by pressing the middle mouse key alone, with the `Shift` key, and with the `Ctrl` key, respectively.
8. The Tree View on the left shows the geometric entities that were used to generate the cylinder. Expand the 1 Part, 1 Body entity and click on Solid to see some properties of the cylinder in the Details View. The pipe bend was generated from two entities:
 - a) **Sketch1**: which can be found in the Plane4 entity. Click on Sketch1 to highlight the circle that the pipe bend is based upon with yellow.
 - b) **Sketch2**: which can be found in the YZPlane entity. Click on the Sketch2 to highlight the path that is swept out by Sketch1 to generate the pipe bend.
9. In the help page search for **keywords** `rotation modes` and select "Rotation Cursors in the Rotate Mode" to find more information on changing the view.
10. Click the `X` button on the `PipeBend [DesignModeler]` tab to close the DesignModeler page. You can click No to quit without saving changes.

Introduction to the Advanced CFD GUI

The tasks associated with CFD simulation in Workbench are referred to as Advanced CFD Tasks. For historical reasons, the GUI for the three Advanced CFD Tasks is slightly different from that of the other Workbench components. We will use CFX-Post to look at the completed simulation of flow through a pipe bend to get a feel for these differences.

1. In the Workbench file area click on the item name PipeBend_001. Under Advanced CFD Tasks, choose Open in CFX-Post to open the results file (PipeBend_001.res). All of the pertinent CFD model data (mesh, flow attributes, and boundary condition information) for this problem is stored in this file.
2. A new page for CFX-Post will open.
3. There are three major areas on the screen: Command menus and buttons at the top, outline and detail panels on the left, and **3D Viewer** window. Wire-frame models of the pipe inlet and outlet should be in the **Viewer**. To see the

pipe bend click the **Domain 1 Default** object on in the tree under **PipeBend_OO1** and Domain 1 in the Outline panel.

4. The mouse button action for controlling the view is similar to that in DesignModeler.
5. The coordinate system triad is shown in the lower right corner. Unlike in DesignModeler, the triad cannot be used to change the view. To set standard directional views type x, y, or z while the Viewer window is active to get views in the positive axis directions and type X, Y, or Y to get views in the negative axis directions. Other standard key mappings can be seen by clicking on the icon at the right of the lower row of icon buttons.
6. On-line help is available, **Help**. Open the main table of contents, **Help/Master Contents**. Context-sensitive help is also available. Right click on Default Legend View 1 object and choose **Edit**. Position the mouse pointer in the **Details of Default Legend View 1** panel and press <F1> to bring up the help page for that panel.
7. This should give a sense of the operation of the Advanced CFD GUI. When you have finished, return to the Workbench Project page. Exit by **File/Close Project** and choose No: do not save any items.
8. Clean up by deleting the CFXTest directory.

2.2 Commands for Duct Bend Example

To set-up the project files and options:

- Create a new folder `N:/Ductbend1` to be the working directory for the project files.
- Open ANSYS Workbench from **Start/Programs/ANSYS 11.0/ANSYS Workbench**. To open a new project:
 1. In the **Start** window, select Empty Project in the **New** panel,
 2. From the menu bar choose **File/Save As ...** to create a project file in your working directory, and
 3. In the **Save As** window fill in **File name:** and click the button.
- From the menu bar choose **Tools/Options ...** to set the length units and meshing tool options:
 - In the **Options** window expand the DesignModeler entity and

¹When NEXUS network traffic is high, it is better to make the working directory on your local machine, i.e. `C:/Temp/Ductbend`.

- * Select **Units** in the tree view on the left to set **Length Unit** ; and
- * Select **Grid Defaults (Meters)** in the tree view on the left to set **Minimum Axes Length** and **Major Grid Spacing** .
- Expand the **Meshing** entity and select **Meshing** to Set **Show Meshing Options Panel at Startup** , **Default Physics Preference** , and **Default Method** .
- Expand the **Common Setting** entity and select **Geometry Import** to:
 - * set **Named Selection Processing** ; and
 - * set **Named Selection Prefixes** (i.e. leave blank).

Click to save the options and close the window,

Geometry Model

The commands listed below will use DesignModeler to create a solid body geometry that will represent the flow domain.

- Under **Create DesignModeler Geometry**, choose New Geometry,
- Check that the desired length unit is **Meter** is selected and click Ok in the units window that appears,
- In the Tree View, select the XYPlane entity and then click the icon to create the Sketch1 entity as a component of the XYPlane.
- To start the sketching, select the tab and click on the Z coordinate of the triad in the lower right corner of the Model View, and draw in the 2D sketch of the flow path;
 1. Select the toolbox and use the tool to sketch the inner wall bend shape:
 - a) Place the cursor over the origin (watch for the P constraint symbol) and left mouse button click.
 - b) Move the cursor to the left along the X axis. With the C constraint visible click the left mouse button to put the start point of the arc on the X axis.
 - c) Sweep the cursor clockwise until the C constraint appears at the Y axis. Click the left mouse button.²
 2. Switch to the toolbox to size the inner wall bend radius:

²Notice that the drawing instruction steps are provided in the lower left corner.

- a) Select the **Radius** tool;
 - b) Select a point on the arc. Then move the cursor to the inside of the arc near the origin. Click to complete a dimension which is labelled R1.
 - c) In the Details View notice that R1 is shown under the **Dimensions** title.
 - d) Change the value of R1 to 0.025 [m]. Notice the arc radius changes automatically. If the dimension is poorly placed on your sketch you can use the **Move** tool to correct the placement.
3. Switch back to the **Draw** toolbox to sketch the inner entrance wall:
- a) With the **Line** tool selected, place the cursor in the lower left quadrant of the XY plane near the arc. Click the left mouse button. Move the mouse cursor down to create a vertical line. Look for the V constraint symbol and click the left mouse button;
 - b) Switch to the **Dimensions** toolbox to size the inner entrance wall length:
 - i. Select the **General** tool;
 - ii. Select a point near the centre of the line. Click and drag the cursor to the right to form the dimension lines. Release the mouse button where the label, V2, is to be placed.
 - iii. In the Details View change the value of V2 to 0.10 [m].
 - c) To join the inner entrance wall and the inner wall bend switch to the **Constraints** toolbox;
 - i. Select the **Coincident** tool;
 - ii. Select the upper end of the entrance inner wall with a left mouse button click. The square end marker should be yellow;
 - iii. Select the square end marker of the arc that lies on the X axis with a left mouse button click. The inner entrance wall should join the inner wall bend.
4. To draw a line across the inflow (entrance):
- a) Use the **Line** tool in the **Draw** toolbox;
 - b) Place the cursor over the bottom end point of the entrance inner wall and notice that a P constraint symbol appears. Left mouse button click to select this point and then move the cursor to the left and click while the H constraint symbol is visible.
 - c) Use the **General** tool in the **Dimensions** toolbox;
 - d) Select a point near the centre of the line. Click and drag the cursor to the bottom to form the dimension lines. Release the mouse button where the label, H3, is to be placed.
 - e) In the Details View change the value of H3 to 0.1 [m].

5. Repeat the procedure used for the entrance inner wall to draw the exit inner wall:
 - a) Draw a horizontal line in the upper right XY quadrant near the end point of the inner wall bend;
 - b) Set the length of the line to 0.25 [m] with the **General** tool from the **Dimensions** toolbox;
 - c) Join the exit inner wall to the inner wall bend with the **Coincident** tool from the **Constraints** toolbox.
6. Draw the outer entrance wall with the **Line** tool. Start at the outer (left) end point of the inflow edge (look for the P constraint symbol) and draw a vertical line that is coincident (C) with the X axis;
7. Draw the outer bend wall with the **Arc by Center** tool. Put the centre at the origin, make the start point at approximately 20° above the X axis in the upper left quadrant, and make the end point coincident (C) with the Y axis. Use the **Coincident** constraint tool to join the start point of the arc to the end point of the outer entrance wall;
8. Draw the outer exit wall with the **Line** tool. Draw a horizontal (H) line coincident (C) with the Y axis above its final desired location. Use the **Coincident** constraint tool to join this line to the end of the outer bend wall. Use the **Equal Length** constraint tool to make the outer exit wall the same length as the inner exit wall; and
9. Draw a line from the end of the outer exit wall to the end of the inner exit wall to form the outflow edge. Make sure that the end points are coincident (P).

The sketch should now be an enclosed contour on the XYPlane.


- To create the three dimensional solid body:
 1. Switch to the Tree View by selecting the **Modeling** tab;
 2. Click on the **Extrude** button to create the Extrude1 feature . In the Details View:
 - Check **Base Object** ,
 - Select **Operation** ▼ ,
 - Select **Direction Vector** ▼ ,
 - Set **FD1, Depth (> 0)** ,
 - Select **As Thin/Surface?** ▼ , and
 - Select **Merge Topology?** ▼ .

3. Click on the **Generate** button to create a Solid. Use the isometric view in the Model View to check that you have a three dimensional solid grey body.
- Name the faces of the solid body to make it easy to apply boundary conditions:
 - Choose **Tools/Named Selection**.
 - In the Details panel set **Named Selection** **Outflow**;
 - In the Graphics View select the outflow face (or surface) and then click **Geometry** **Apply** in the Details View;
 - Click on the **Generate** button to complete the named selection process;
 - Repeat for surfaces named Front, Back, InnerWall, OuterWall, and Inflow. Some faces, like InnerWall and OuterWall, may be composed of three primitive surfaces. To select a set of faces hold the "Ctrl" key down while clicking on the component faces in the Graphics View.
 - Save an image of the geometry by clicking on the **Image Capture** (camera) button. Set **File name:** **Geometry** to save the png format file.
 - Choose **File/Save As ...** and set **File name:** **Ductbend.agdb** in the **Save As** window. Click **Save** to close window.
 - Return to the Project page by clicking on the **Ductbend [Project]** tab at the top left corner of the window.

ANSYS Mesh Generation

The commands listed below use ANSYS swept mesher³ to generate a discrete hexahedral mesh in the flow domain:




- Choose the **New Mesh** DesignModeler Tasks; Notice the three primary areas: Geometry View, Outline View, and Details View, in the Meshing window.
- In the outline view, right click on the **Mesh** entity and select **Generate Mesh**. Notice that a simple hexahedral mesh is generated with automatic settings. To achieve a realistic CFD simulation this mesh is modified by:
 1. Ensure that a structured hexahedral mesh is produced by:
 - a) Select the **Face** Selection Filter icon from the button commands at the top of the meshing window;
 - b) Right click on the **Mesh** entity and select **Insert/Mapped Face Meshing**;
 - c) On the Geometry View select the Front face;⁴ and





³For CFX-Meshing tools see the section on CFX Mesh Generation, page 27.

⁴The design of the margin sketches used in this section was suggested by Dr. K.J. Hsieh

- d) then click **Geometry** in the Details View.
2. Set the mesh one unit wide in the z direction by:
- Select the **Edge** Selection Filter icon from the button commands at the top of the meshing window;
 - Right click on the Mesh entity and select **Insert/Sizing**;
 - On the Geometry View select one of edges between the front and back faces at the outflow and then click **Geometry** in the Details View;
 - In the Details View set
 - **Type**
 - **Number of Divisions**
 - **Edge Behaviour**
 - **Bias Type**
 - right click on the Mesh entity and select **Generate Mesh**.
3. Set the mesh spacing in the cross-stream direction so that it is fine near the walls and coarse in the core by:
- Right click on the Mesh entity and select **Insert/Sizing**;
 - On the Geometry View select the front edge at the inflow between outer and inner walls and the front edge at the outflow between the walls (remember to use the "Ctrl" key) and then click **Geometry** in the Details View;
 - In the Details View set
 - **Type**
 - **Number of Divisions**
 - **Edge Behaviour**
 - **Bias Type**
 - **Bias Factor**
 - right click on the Mesh entity and select **Generate Mesh**.
4. Set a uniform mesh spacing in the streamwise direction in the entrance region by:
- Right click on the Mesh entity and select **Insert/Sizing**;
 - On the Geometry View select the front edges of the inner and outer walls in the entrance region and then click **Geometry** in the Details View;
 - In the Details View set
 - **Type**
 - **Element Size**



- **Edge Behaviour**
 - **Bias Type**
- d) right click on the Mesh entity and select **Generate Mesh**.
5. Set uniform mesh spacing in the streamwise direction direction in the bend region by:
- a) Right click on the Mesh entity and select **Insert/Sizing**;
 - b) On the Geometry View select the front edge of the inner bend wall and then click **Geometry** in the Details View;
 - c) In the Details View set
 - **Type**
 - **Number of Divisions**
 - **Edge Behaviour**
 - **Bias Type**
 - d) right click on the Mesh entity and select **Generate Mesh**.
- 
6. Set an expanding mesh spacing in the stream direction of the exit region by:
- a) Right click on the Mesh entity and select **Insert/Sizing**;
 - b) On the Geometry View select the front edges of the inner and outer walls in the exit region and then click **Geometry** in the Details View;
 - c) In the Details View set
 - **Type**
 - **Element Size**
 - **Edge Behaviour**
 - **Bias Type**
 - **Bias Factor**
 - d) right click on the Mesh entity and select **Generate Mesh**.
- 
7. Save an image of the mesh by selecting **New Figure or Image** ▼ from the icons above the graphics window. Set **File name:** to save the png format file.
8. Save the mesh with **File/Save** and set **File name:** ;
9. Return to the Project page by clicking on the tab at the top left corner of the window.

Pre-processing

In this phase the complete CFD model (mesh, fluids, flow processes, boundary conditions, etc.) is defined and saved in a hierarchical database.

To accomplish these steps execute the following commands:

- Highlight the Mesh Model, `Ductbend.cmdb`, in the Project page and select Create CFD Simulation with Mesh under Advanced CFD Tasks;
- After a short wait the **CFX-Pre** page will open. This page is similar to the **CFX-Post** page. There are three main areas: the menus and command buttons at the top, the Viewer window at the right, and the Outline view of the database trees at the left;
- To create a new material with the required water properties, right mouse click on the Materials entity in the Outline tree and select **Insert/Material**. In the **Insert Material** panel, fill in **Name** `Water nominal` and click **OK** to open a panel with two tabs:
 - Click the **Basic Settings** tab and set:
 - **Option** ▼ `Pure Substance`,
 - **Material Group** ▼ `Constant Property Liquids`,
 - **Material Description** off,
 - **Thermodynamic State** on and **Thermodynamic State** ▼ `Liquid`.
 - Click the **Material Properties** tab and set:
 - **Option** ▼ `General Material`,
 - in the **Equation of State** area set,
 - **Option** ▼ `Value`,
 - **Density** `1000` ▼ `kg m-3`,
 - expand **Transport Properties** `+`,
 - **Dynamic Viscosity** on and **Dynamic Viscosity** `0.001` ▼ `Pa · s`,

and then click **OK**.
- In the Outline view, right mouse click the Simulation Type entity and select **Edit** to open the **Simulation Type** panel. Check that **Option** ▼ `Steady State` is set and then click **OK**.
- In the Outline view, double left mouse click the Default Domain entity to open the **Domain: Default Domain** panel which will have several tabbed sub-panels.

- On the **General Options** sub-panel, set:
 - * **Location** ▼ B28 and notice that the geometry is highlighted in green in the Viewer window,
 - * **Domain Type** ▼ Fluid Domain,
 - * **Fluids List** ▼ Water nominal,
 - * **Particle Tracking** off,
 - * **Reference Pressure** 1 ▼ atm,
 - * **Buoyancy Option** ▼ Non Buoyant, and
 - * **Domain Motion Option** ▼ Stationary.
- on the **Fluid Models** sub-panel set:
 - * **Heat Transfer Model Option** ▼ None,
 - * **Turbulence Model Option** ▼ k-Epsilon,
 - * **Turbulent Wall Functions Option** ▼ Scalable,
 - * **Reaction or Combustion Model Option** ▼ None, and
 - * **Thermal Radiation Model Option** ▼ None,
- on the **Initialization** sub-panel ensure that **Domain Initialization** is off and then click **Ok** to close the panel.
- To prepare for implementing the boundary conditions, expand the expand **+ Ductbend.cmdb** mesh model to see the Principal 2D Regions of the geometry. Check that all 2D regions are highlighted.
- Right mouse click **Back** and select **Insert/Boundary** to open the boundary details panel. In this panel:
 - under the **Basic Settings** tab set:
 - * **Boundary Type** ▼ Symmetry, and
 - * **Location** ▼ Back,

and then click **Ok** to close the panel and create the new boundary object. Notice that perpendicular red arrows appear on the back surface in the **Viewer** window and the boundary object is listed in the Default Domain entity. Clicking on back surface object in the Default Domain database causes the back surface mesh to be outlined with green in the **Viewer** window. A double mouse click will re-open the boundary details panel.

- Right mouse click **Front** and select **Insert/Boundary** to open the boundary details panel. In this panel:

- under the **Basic Settings** tab set:
 - * **Boundary Type** ▼ Symmetry, and
 - * **Location** ▼ Front,

and then click **Ok** to close the panel.

- Right mouse click Inflow and select **Insert/Boundary** to open the boundary details panel. In this panel:

- under the **Basic Settings** tab set:
 - * **Boundary Type** ▼ Inlet, and
 - * **Location** ▼ Inflow,
- and under the **Boundary Details** tab set:
 - * **Flow Regime Option** ▼ Subsonic,
 - * **Mass and Momentum Option** ▼ Normal Speed,
 - * **Normal Speed** ▼ 3 ▼ $m s^{-1}$,
 - * **Turbulence Option** ▼ Intensity and Length Scale,
 - * **Value** 0.05,
 - * **Eddy Length Scale** 0.01 ▼ m,

and then click **Ok** to close the panel and create the new boundary object.

- Right mouse click inner wall and select **Insert/Boundary** to open the boundary details panel. In this panel:

- under the **Basic Settings** tab set:
 - * **Boundary Type** ▼ Wall, and
 - * **Location** ▼ InnerWall,
- and under the **Boundary Details** tab set:
 - * **Wall Influence on Flow Option** ▼ No Slip,
 - * **Wall Velocity** off,
 - * **Wall Roughness Option** ▼ Smooth Wall,

and then click **Ok** to close the panel.

- Right mouse click OuterWall and select **Insert/Boundary** to open the boundary details panel. In this panel:

- under the **Basic Settings** tab set:
 - * **Boundary Type** ▼ **Wall**, and
 - * **Location** ▼ **OuterWall**,
- and under the **Boundary Details** tab set:
 - * **Wall Influence on Flow Option** ▼ **No Slip**,
 - * **Wall Velocity** off,
 - * **Wall Roughness Option** ▼ **Smooth Wall**,

and then click **Ok** to close the panel.

- Right mouse click **Outflow** and select **Insert/Boundary** to open the boundary details panel. In this panel:

- under the **Basic Settings** tab set:
 - * **Boundary Type** ▼ **Outlet**, and
 - * **Location** ▼ **Outflow**,
- and under the **Boundary Details** tab set:
 - * **Flow Regime Option** ▼ **Subsonic**,
 - * **Mass and Momentum Option** ▼ **Static Pressure**,
 - * **Relative Pressure** **0** ▼ **Pa**,

and then click **Ok** to close the panel.

- Right mouse click on **Solver Control** entity and select **Edit** to open the Details of Solver Control panel. Under the **Basic Settings** tab set:

- **Advection Scheme Option** ▼ **High Resolution**,
- **Max No. Iterations** **75**,
- **Timescale Control** ▼ **Auto Timescale**,
- **Length Scale Option** **Conservative**,
- **Timescale Factor** **1.**,
- **Residual Type** ▼ **MAX**,
- **Residual Target** **1.0e-3**,

and then click **Ok**.

- Right mouse click on **Output Control** entity and select **Edit** to open the Details of Output Control panel. Under the **Results** tab set:
 - **Option** ▼ **Standard**,
 - **Output Variable Operators** on and choose ▼ **All**, and
 - **Output Boundary Flows** on and choose ▼ **All**,
 and then click **Ok**.
- Save an image of the model by choosing **File/Print ...** and in the **Print** panel set:
 - **File** **model.png**, and
 - **Format** ▼ **PNG**
 followed by **Print**. The plot will be printed to the file `model.png` in your working directory.
- On the row of buttons below the menu bar above the Viewer window, click the **Write Solver File** icon (last one in the row) to open the panel. Accept the default filename, `Ductbend.def` and **Operation** ▼ **Start Solver Manager**.

Solver Manager

The CFX-Solver window will open after CFX-Pre closes. In the **Define Run** panel set:

- **Definition File** **ductbend.def** (NOTE: If restarting a partially converged run, you would enter the name of the most current results file),
- **Type of Run** ▼ **Full**, and
- **Run Mode** ▼ **Serial**,

and then click **Start Run**.

After a few minutes execution should begin. Diagnostics will scroll on the terminal output panel and the equation RMS residuals will be plotted as a function of time step. After the first few time steps, the residuals should fall monotonically. Execution should stop within 50 time steps. In the **ANSYS CFX Solver Finished Normally** window click **Process Results Now**.

Post-processing

To create and save a vector plot:

- Choose **Insert/Vector**, accept **Name** , and click to define a vector object and open an edit panel. In the panel set:
 - **Locations** ▼ ,
 - **Reduction** ,
 - **Factor** (plots vector at every mesh point),
 - **Variable** ▼ ,
 - **Hybrid** on,
 - **Projection** ▼ ,

and click . The vector plot should appear in the **3D Viewer** window and the vector object is listed in the User Locations and Plots database tree. Turn **Default Legend View 1** off and back on to remove and then replace the scale legend. Turn **Wireframe** off and on. Orthographic projection (type "Shift Z" while in Graphics window) will work best for two-dimensional views. Notice that if you double-click on an object in the database tree then a details panel opens up for that object.

- Choose **File/Print ...** and in the **Print** panel set:

- **File** , and
- **Format** ▼

followed by .

To create and plot the vorticity field:

- Choose **Insert/Variable** and in the **New Variable** definition window set **Name** and click . In **Vorticity** edit panel (lower left):
 - set **Method** ▼ ,
 - set **Scalar** on,
 - fill in **Expression** , and
 - click .
- Choose **Insert/Contour**, accept **Name** , and click to define a fringe/contour plot object and open an edit panel. In the panel set:

- **Locations** ▼
- **Variable** ▼

and click . The fringe plot should appear in the **3D Viewer** window.

To output the velocity values along a straight line across the duct:

- Choose **Insert/Location/Line**, accept **Name** , and click to define a line object and open an edit panel. Use **Method** ▼ , set Point 1 to (0.0,0.125,0.01), set Point 2 to (0.0,0.025,0.01), set the number of samples to 25, and click to see the line (make sure that the visibility of the contour plot, etc. is turned off).
- Choose **File/Export ...** to open the Export panel where you can:
 - set **File** ,
 - select Line 1 from the **Locations** list,
 - set **Export Geometry Information** on,
 - select (Ctrl key plus click) Velocity u and Velocity v from the **Select Variable(s)** list, and
 - click to write the data to a file in a comma-separated format that can be imported into a conventional spreadsheet program for plotting or further analysis. Notice that this file includes x, y, and z values.

To export the inner wall pressure and wall shear stress distribution:

- Choose **Insert/Location/Plane**, accept **Name** , and click to define a plane object and open an edit panel. Use **Method** ▼ with $Z = 0[m]$ and click (turn highlighting off to avoid clutter in the view).
- Choose **Insert/Location/Polyline**, accept **Name** , and click to define a polyline object. In the edit panel use **Method** ▼ with **Boundary List** ▼ and **Intersect With** ▼ and then click . This creates a line that follows the inner wall. You can follow the steps for export along a line to export the values of the pressure, total pressure, and wall shear (stress) along this line into the data file `wall.csv`.

To probe the velocity field at a point:

- Choose **Insert/Location/Point**, accept **Name** , and click to define a point object. Use **Method** ▼ and initialize the point to (0.10,0.04,0)

before clicking **Apply**. Choose **Tools/Function Calculator** to open the **Function Calculator** panel. Use **Function** ▼ **probe**, **Location** ▼ **Point 1**, **Variable** ▼ **Velocity u.Gradient X** (Note: Use the **...** to get a list of all possible variables.) before clicking on the **Calculate** button. The result with units appears in the Result box. Move the point around to probe other regions in the flow.

To save the visualization state:

- Choose **File/Save State** and enter `tutorial11.cst` for the file name to save all of the information associated with the visualization and post-processing objects you have created in this session. You can load this state file (**File/Load State**) to recreate these objects and images in later sessions. This facility allows easy comparison of results between simulations.
- Return to the Project page and choose **File/Exit**. Select Yes to save highlighted files.

Clean Up

The last step is to remove unnecessary files created by CFX. This step is necessary to ensure that you do not exceed your disk quota. At the end of each session⁵ delete all files except:

- *.agdb, *.cmdat, *.cmdb, *.wbdb, *.def and *_*.res files.

If you no longer need your results but would like to be able to replicate them then you should delete all files except:

- *.def files.

After removing all unnecessary files, use the WinZip utility to compress the contents of your directory.




CFX Mesh Generation

The commands below replace those in the section ANSYS Mesh Generation. These new commands generate an unstructured mesh with the CFX-Meshing tools:

- Choose the New Mesh DesignModeler Tasks; Notice the three primary areas: Graphics View, Outline View, and Details View, in the Meshing window.
- In the outline view, right click on the Mesh entity and select **Generate Mesh**. Notice that a simple hexahedral mesh is generated with automatic settings. To achieve a realistic CFD simulation continue;
- Switch the meshing method by:

⁵If you have used a local temp drive, remember to copy your work to your N: drive

1. Select the **Body** Selection Filter icon from the button commands at the top of the meshing window;
 2. Right click on the **Mesh** entity and select **Insert/Method**;
 3. On the Geometry View select the solid body; and in the Details View:
 - click **Geometry** **Apply** and
 - set **Method** **CFX-Mesh**;
 4. Right click on the **Mesh** entity and select **Edit in CFX-Mesh**. Notice that a new tab, **CFX-Mesh** opens. Select this tab.
- In the Tree View, select **Options** to see the mesh options in the Details View:
 - Set **Surface Meshing** **Advancing Front**,
 - Set **Meshing Strategy** **Extruded 2D Mesh**,
 - Set **2D Extrusion Option** **Full**, and
 - Set **Number of Layers** **1**;
 - In the Tree View, expand the **Spacing** entity;
 - Select the **Default Body Spacing** entity to open the Body Spacing Details View. Set **Maximum Spacing [m]** **0.01**.
 - Left mouse click on the **Extruded Periodic Pair** entity;
 - In the Graphics View select the front surface and then click **Location 1** **Apply** in the Details View;
 - In the Graphics View select the back surface (remember to use the location planes in the lower left corner of the Graphics View) and then click **Location 2** **Apply** in the Details View; and
 - Set **Periodic Type** **Translational**;
 - In the Tree View, click on **Inflation** entity and in the Details View set **Number of Inflated Layers** **10**.
 - In the Tree View, right mouse click on **Inflation** and select **Insert/Inflated Boundary** to create an Inflated Boundary entity. Select the three surfaces of the inner wall in the Graphics View for the Location and set **Maximum Thickness [m]** **0.03**;
 - Repeat to create an Inflated Boundary of **Maximum Thickness [m]** **0.03** on the outer wall;



- In the Tree View right mouse click on Preview entity and select **Generate Surface Meshes**. Progress is shown in the lower left corner. After a short time you should see a mesh of triangles and rectangles on the surfaces of the solid;
- Click the icon on the top row of icons/buttons. Again, progress is shown in the lower left corner. When this process is completed, go to the Tree View and check that Errors does not exist or that it is empty.
- Return to the Meshing page by clicking on the tab.
- Save an image of the mesh by selecting **New Figure or Image ▼** from the icons above the graphics window. Set **File name:** to save the png format file.
- To close this phase, select **File/Save As ...** and set **File name:** .
- Return to the Project page by clicking on the tab at the top left corner of the window.

Instructions for creating the CFX simulation continue in the section Pre-processing on page 20.

Part II

Additional Notes

Chapter 3

Geometry and Mesh Specification

In the first steps of the CFD computer modelling, the solution domain is created in a digital form and then subdivided into a large number of small finite elements or volumes.

3.1 Basic Geometry Concepts and Definitions

Vertex: Occupies a point in space. Often other geometric entities like edges *connect* at vertices.

Edge: A curve in space. An *open edge* has beginning and end vertices at distinct points in space. A straight line segment is an open edge. A *closed edge* has beginning and end vertices at the same point in space. A circle is a closed edge.

Face: An enclosed surface. The surface area inside a circle is a *planar face* and the outer shell of a sphere is a *non-planar face*. An *open face* has all of its edges at different locations in space. A rectangle makes an open face. A *closed face* has two edges at the same location in space. The cylindrical surface of a pipe is a closed face.

Solid: The basic unit of three dimensional geometry modelling:

- is a space completely enclosed in three dimensions by a set of faces (*volume*);
- the surface faces of the solid are the the external surface of the flow domain; and
- holes in the solid represent physical solid bodies in the flow domain such as airfoils.

Part: One or more solids that form a flow domain.

Multiple Solids: May be used in each part:

- the solid volumes cannot overlap;
- the solids must join at common surfaces or faces; and
- the faces where two solids join can be *thin surfaces*

Thin Surface: A thin solid body in a flow like a guide vane or baffle can be modelled as an infinitely thin surface with no-slip walls on both sides.

Units: To keep things simple and to minimize errors, use metric units throughout.

Advanced Concepts: See the Geometry section of the CFX-Mesh Help for further information on geometry modelling requirements. To develop improved skill follow the tutorials given in CFX-Mesh Help/Tutorials.

3.2 Geometry Creation

The basic procedure for creating a three dimensional solid geometry is to make a 2D sketch of an enclosed area (possibly with holes) on a flat plane. The resulting 2D sketch is a profile which is swept through space to create a 3D solid feature. This process can be repeated to either remove portions of the 3D solid or to add portions to the solid.

Each sketch is made on a *Plane*:

- There are three default planes, XYPlane, XZPlane, and YZPlane, which coincide with the three planes of the Cartesian coordinate system;
- Each plane has a local X-Y coordinate system and normal vector (the plane's local Z axis);
- New planes can be defined based on: existing planes, faces, point and edge, point and normal direction, three points: origin, local X axis, and another point in plane, and coordinates of the origin and normal; and
- Plane transforms such as translations and rotations can be used to modify the base definition of the plane.

The creation of a sketch is similar to the creation of a drawing with modern computer drawing software:

- A sketch is a set of edges on a plane. A plane can contain more than one sketch;
- The sketching toolbox contains tools for drawing a variety of common two dimensional shapes;
- *Dimensions* are used to set the lengths and angles of edges;
- *Constraints* are used to control how points and shapes are related in a sketch. Common constraints include:

Coincident (C): The selected point (or end of edge) is coincident with another shape. For example, the end point of a new line segment can be constrained to lie on the line extending from an existing line segment. Note that the two line segments need not touch;

Coincident Point (P): The selected points are coincident in space;

Vertical (V): The line is parallel to the local plane's Y axis;

Horizontal (H): The line is parallel to the local plane's X axis;

Tangent (T): The line or arc is locally tangent to the existing line or arc;

Perpendicular (\perp): The line is perpendicular to the existing line; and

Parallel (\parallel): The line is parallel to the existing line.

As a sketch is drawn the symbols for each relevant constraint will appear. If the mouse button is clicked while a constraint symbol is on the sketch then the constraint will be applied. Note that near the X and Y axes it is often difficult to distinguish between coincident and coincident point constraints; and

- *Auto-Constraints* are used to automatically connect points and edges. For example, if one edge of a square is increased in length the opposite edge length is also increased so that the shape remains rectangular.

Features are created from sketches by one of the following operations:

Extrude: Sweep the sketch in a particular direction (i.e. to make a bar);

Revolve: Sweep the sketch through a revolution about a particular axis of rotation (i.e. to make a wedge shape);

Sweep: Sweep the sketch along a sketched path (i.e. to make a curved bar); and

Skin/Loft: Join up a series of sketches or profiles to form the 3D feature (like putting a skin over the frame of a wing).

Features are integrated into the existing active solid with one of the following Boolean operations:

Add Material: Merge the new feature with the active solid;

Cut Material: Remove the material of the new feature from the active solid;

Slice Material: Remove a section from an active solid; and

Imprint Face: Break a face into two parts. For example, this will open a hole on a cylindrical pipe wall.

Sometimes it is necessary to use multiple solids in a single part. These solids must share at least one common face. This common face might be used to model a thin surface in the flow solver. In this case:

1. Select active solid with the body selection filter turned on;
2. Freeze the solid body to stop the Boolean merge or remove operations (**Tools/Freeze**). This will form a new solid body as a component of a new part; and
3. Select all solids and choose **Tools/Form New Part**.

The geometry database contains a list of primitive faces and edges that are formed in the generation processes. It is often cumbersome to work directly with these primitive entities. Therefore, there is a facility for naming selected surfaces. These named selections are passed on to the meshing tools and to CFX-Pre.

When the solid model is completed an .agdb file is created and saved in order to store the geometry database.

3.3 Mesh Generation

The mesh generation phase can be broken down into the following steps:

1. Read in or update the .agdb file with the solid body geometry database;
2. Set the properties of the mesh;
3. Cover the surfaces of the solid body with a surface mesh of triangular or quadrilateral elements; and
4. Fill the interior of the solid body with a volume mesh of tetrahedral, hexahedral, or prism elements (see Figure 3.1) that are based on the surface meshes. A .cmdb file containing all of the mesh information and named selection information is written at the end of this step.




Figure 3.1: Shapes of common three dimensional elements.

Two strategies suitable for simulating two-dimensional flow fields are discussed here: mapped meshing and free tetrahedral (tet) meshing with surface inflation. Examples of these meshes are shown in Figure 3.2. In both example meshes, the front and back surfaces have identical surface meshes which are swept through space to create volume meshes that are one element thick in the direction of negligible flow changes. However, the example surface meshes differ in the shape and topology of

their surface elements. The mapped mesh is comprised solely of quadrilateral elements, Figure 3.3. The free tet mesh with surface inflation has triangular elements well away from the inner and outer walls and quadrilateral elements adjacent to the walls.




Figure 3.2: Example meshes showing a mapped mesh and a free tetrahedral mesh with surface inflation.

Generally speaking mapped meshing strategies provide better meshes for CFD simulations than provided by free tet meshing strategies. However, for a mapped meshing strategy to work on a surface it must be possible to:

- decompose the surface into a set of sub-surfaces each of which are enclosed by four edges; and
- impose the same number of mesh intervals, N , on pairs of opposing edges for each sub-surface.




Figure 3.3: Shapes of common two dimensional elements.

Figure 3.2 shows three sub-surfaces outlined in blue and shows the number of mesh intervals for each edge on the mapped mesh.

For complex surfaces and volumes it is often difficult or impossible to meet the requirements for mapped meshing. In this case free tet meshing is a viable alternative strategy except in boundary layer regions. In these layers the need for a fine mesh scale normal to the wall leads to triangular (3D) or quadrilateral (2D) prisms as shown in Figure 3.2. These special mesh layers are referred to as *inflation* layers.

Notes on controlling these two meshing strategies are given in the next two sections.

ANSYS: Mapped Meshing

The ANSYS meshing tools include a number of strategies and have been highly automated. They have been developed to provide reasonable meshes for stress/failure analysis simulations in solid members. In stress/failure analysis a reasonable mesh can often be established based on the geometry of the solid member. This is not true for fluid flow simulations where special attention is required for flow features like separation zones which do not directly follow the domain geometry. Therefore, the user should expect to provide a lot of input into the mesh design.

As mentioned above, mapped meshing is applied to sub-surfaces that are enclosed by four edges with opposing edge pairs having the same number of mesh elements. The quadrilateral mesh vertices within a sub-surface are determined by interpolating the vertex locations on the edges. The overall mapped mesh properties are controlled by:

- **Blocking:** the decomposition of surfaces into sub-surfaces; and
- **Edge Sizing:** the placement of vertices along edges.

While the blocking process in ANSYS meshing is highly automated, it can be controlled by creating edges in the geometry which will naturally lead to desired sub-surfaces and by ensuring that edge element counts are the same on opposing edges of desired sub-surfaces.

Figure 3.4 shows how blocking is influenced by edge sizing and available geometry edges. In the left mesh, edge sizing is set on the two left vertical edges. The blocking is established so that the mesh spacing is uniform on the single right vertical edge. In the mesh on the right, the right vertical edge is composed of two un-merged edges and the edge sizing is set on opposing pairs of upper and lower vertical edges.

The meshing software creates a Mesh entity which can have the following controls associated with it to control the mesh:

Mapped Face Meshing: applied to a surface ensures that a mapped or structured quadrilateral mesh is created on the surface;

(Edge) Sizing: applied to an edge or set of edges controls the vertex location along an edge by setting:




Figure 3.4: Meshes showing the influence of edge sizing specification on mesh blocking. The mesh on the left has edge sizing set on the two left vertical edges. The mesh on the right has edge sizing set on right and left vertical edges.

Type:

Element Size: sets the average of the elements lengths, Δ , along the edge; or

Number of Divisions: sets the number, N , of elements along the edge;

Note that $L = N\Delta$ where L is the edge length.

Edge Behaviour: sets whether the mesh spacing and placement are rigidly enforced, **Edge Behaviour** ▼ , or can be modified by the automatic meshing routines, **Edge Behaviour** ▼ ;

Bias: sets the placement of vertices along an edge to one of the following patterns: **None** or uniform spacing, **Decreasing** spacing, **Increasing** spacing, **Increasing-Decreasing** spacing, and **Decreasing-Increasing** spacing.

For each pattern, the mesh spacing increases or decreases by a fixed expansion ratio, r , between adjacent elements. Table 3.1 gives relationships between edge length, number of elements, expansion ratio, bias factor, and smallest and largest element lengths.

The bias direction is automatically determined in the blocking algorithm.

Bias Factor: Is the ratio of largest element length to the smallest element length along an edge.

CFX-Mesh: Free Tet Meshing with Inflation

The following comments and guidelines are for generating tetrahedral meshes with surface inflation for two-dimensional flow simulation in relatively simple geometries.

Pattern	Length Relationship	Bias Factor	Smallest Length	Largest Length
Increasing ($r > 1$)	$L = \delta_1 \left(\frac{1-r^N}{1-r} \right)$	r^{N-1}	δ_1	$\delta_1 r^{N-1}$
Decreasing ($r < 1$)	$L = \delta_1 \left(\frac{1-r^{-N}}{1-r^{-1}} \right)$	$r^{-(N-1)}$	$\delta_1 r^{N-1}$	δ_1
Increasing - Decreasing ($r > 1$), N even	$L = 2\delta_1 \left(\frac{1-r^{\frac{N}{2}}}{1-r} \right)$	$r^{\frac{N}{2}-1}$	δ_1	$\delta_1 r^{\frac{N}{2}-1}$
Decreasing - Increasing ($r < 1$), N even	$L = 2\delta_1 \left(\frac{1-r^{-\frac{N}{2}}}{1-r^{-1}} \right)$	$r^{-(\frac{N}{2}-1)}$	$\delta_1 r^{\frac{N}{2}-1}$	δ_1

Table 3.1: Length relationships for various bias patterns.

Mesh Features

The mesh is composed of two dimensional triangular and quadrilateral elements on the surfaces and tetrahedral (fully 3D meshes) and prism elements in the body of the solid.

The properties of the mesh are controlled by the settings of the following features:

Default Body Spacing: Set the maximum length scale of the tetrahedral elements throughout the volume of the body. Some of the actual tetrahedral elements may be smaller due to the action of other mesh features or in order to fit the tetrahedral elements into the body shape.

Default Face Spacing: Set the length scale of the triangular elements on the surfaces.

- For simple meshes it is sufficient to set **Face Spacing Type** ▼ Volume Spacing.
- For surfaces such as an airfoil in a large flow domain, it might be desirable to set the triangular mesh length scale smaller than the default body spacing. In this case a new Face Spacing can be defined and assigned to the airfoil surface. Besides setting the triangular element length scale, the following properties must be set for the new face spacing:
 - Radius of Influence:** The distance from the region that has a tetrahedral mesh length scale equal to that of the surface triangular elements;
 - Expansion Factor:** The rate at which the tetrahedral mesh length scale increases outside the radius of influence. This value controls how smoothly the mesh length scale increases from the face region to the default body spacing far from the face.

- For complex surfaces the face spacing type should be set so that the geometry of the surface is well represented by the mesh: relative error or angular resolution.

Controls: are used to locally decrease the mesh length scale in the region around a point, line, or triangular plane surface. The spacing in the vicinity of a control is set by three factors:

Length Scale: fixes the size of the tetrahedral mesh elements;

Radius of Influence: sets the distance from the control that has a mesh of the specified length scale; and

Expansion Factor: controls how smoothly the mesh length scale increases to the default body spacing far from the control.

For line and triangle controls, the spacing can be varied over the control (i.e. from one end point of the line to the other end point).

Extruded Periodic Pair: In cases where the flow is two dimensional, it is desirable to have a single mesh element in the cross-stream direction. In these cases the surface meshes on two surfaces will need to be identical (i.e. the face mesh on the first surface can be uniquely mapped onto the second surface). In other cases where the flow is three dimensional, it may still be desirable to have identical face meshes on two bounding surfaces. For example, this is useful in periodically repeating geometries.

Each Periodic Pair is defined by two surfaces and a two dimensional planar (**Periodic Type** ▼ Translational) or axisymmetric (**Periodic Type** ▼ Rotational) mapping.

Inflation: In boundary layer regions adjacent to solid walls it is often desirable to make a very small mesh size in the direction normal to the wall in order to resolve the large velocity shear strain rates. If tetrahedral meshes are used in this region there will either be a large number of very small elements with equal spacing in all directions (i.e. *isotropic* elements with vertex angles close to 60°) or very thin squashed elements. These choices are either inefficient or inaccurate. A better element shape in this region is a triangular (3D) or quadrilateral (2D) prism based on the surface mesh. The basic shape of the prism element is independent of the height of the prism (mesh length scale normal to the wall). The layer of prism elements is an inflated boundary with:

Maximum Thickness: that is often approximately the same as the default body mesh spacing; or

First Layer Thickness: that is often set by the properties of the local turbulent boundary layer. Other properties include:

Number of Inflated Layers: specifies the number of prism elements across the thickness of the inflated layer; and

Expansion Factor: specifies how the prism height increases with each inflated layer above the wall surface. This factor must be between 1.05 and 1.35.

Stretch: The default body mesh length scale is isotropic. The vertex angles in the isotropic tetrahedral elements are close to 60° . In geometries that are not roughly square in extent, it may be desirable make the mesh length scale longer or shorter in one particular direction. This is achieved by stretching the geometry in a given direction, meshing the modified geometry with an isotropic mesh, and then returning the geometry (along with the mesh) to its original size. This means that if the y direction is stretched by a factor of 0.25 without stretching in the other two directions then the mesh size in the y direction will be roughly 4 times that of the other directions. Take care to ensure that the resulting tetrahedral elements do not get too squashed. For this reason the stretch factors should be between 0.2 and 5 at the very most (more moderate stretch factors are desirable). **Note:** stretch parameters are ignored in extruded meshes.

Proximity: flags set the behaviour of the mesh spacing when edges and surfaces become close together. For simple rectangular geometries set **Edge Proximity** **No** and **Surface Proximity** **No**.

Options: are used for setting the output filename and for setting the algorithms used for generating the volume and surface meshes:

Surface Meshing **Delaunay** is a fast algorithm for creating isotropic surface meshes. Suited to complex surface geometries with small mesh spacing.

Surface Meshing **Advancing Front** starts at the edges of the surface and is a similar algorithm to the volume meshing algorithm described above. Since it creates regular meshes on simple rectangular type surfaces, it is the recommended algorithm.

Meshing Strategy **Extruded 2D Mesh** is an algorithm for generating meshes in geometries that are effectively 2D. A surface mesh is extruded through space by either translation or rotation from one face to a matching face in the periodic pair. This option is useful for simulating two dimensional flows and flows in long constant area ducts. The number of elements (often 1) and mesh spacing distribution in the extruded direction can be specified.

Meshing Strategy **Advancing Front and Inflation 3D** is the primary algorithm for generating meshes in 3D geometries. The algorithm starts with a surface mesh and then builds a layer of tetrahedral elements over the surface based on the surface triangular elements. This creates a new surface. The process is repeated advancing the layers of tetrahedral elements into the interior of the volume.

Volume Meshing ▼ Advancing Front does the calculations with a single computer. An option for generating the volume mesh in parallel on a network of computers exists.

Chapter 4

CFX-Pre: Physical Modelling

CFX-Pre is a program that builds up a database for storing all of the information (geometry, mesh, physics, and numerical methods) used by the equation solver. The contents of the database is written to a `def` (definition) file.

The database is organized as a hierarchy of objects. Each object in the hierarchy is composed of sub-objects and parameters. There are two main objects: **Flow** and **Library**. The **Flow** object holds all of the data on the flow model and the **Library** object holds the property data for the fluids.

The major components of the **Flow** object are organized in the following hierarchy:

- **Flow**
 - **Domain**
 - * *Fluids List* (not explicitly shown in the **Physics** panel)
 - * **Boundary**
 - * **Domain Models**
 - **Domain Motion**
 - **Reference Pressure**
 - * **Fluid Models**
 - **Heat Transfer Model**
 - **Turbulence Model**
 - **Turbulent Wall Functions**
 - **Initialization**
 - **Output Control**
 - **Simulation Type**
 - **Solver Control**
 - * **Advection Scheme**
 - * **Convergence Control**
 - * **Convergence Criteria**

CFX-Pre provides easy access to the components of these two main objects through the object trees, **Simulation** and **Materials** in the Outline panel. For most components edit panels are available and provide guidance on the possible parameter settings.

4.1 Domain

Fluids List

A fluid (or mixture of fluids in more complex multi-phase flows) has to be associated with each domain. The fluid for a particular domain can be selected from the fluid library which has many common fluids. The **Materials** tree shows the fluid library. There are provisions for selecting pre-defined fluids, defining new fluids, and creating duplicates or copies of existing fluids.

The properties of fluids can be general functions of temperature and pressure for liquids or gases. The CFX Expression Language, CEL is used to input formulae for specifying equations of state and other applications such as boundary variable profiles, initialization, and post-processing. CEL allows expressions with standard arithmetic operators, mathematical functions, standard CFX variables, and user-defined variables. All values must have consistent units and variables in CEL expressions must result in consistent units. Full details of CEL, including the names of the standard CFX variables, are included in the *ANSYS CFX Reference Guide*.

For low speed flows of gases and liquids it is adequate to use constant property fluids. It is easiest to build up a new constant property fluid from a comparable fluid from the existing CFX fluid library as a template. For example, to define constant property air at 20 °C, make a duplicate copy of air at 25 °C and then edit this copy.

Boundary

Throughout each domain, mass and momentum conservation balances are applied over each element. These are universal relationships which will not distinguish one flow field from another. To a large extent, a particular flow field for a particular geometry is established by the boundary conditions on the surfaces of the domain.

A standard boundary condition object includes a name, a type, a set of surfaces, and a set of parameter values.

Boundary condition types include:

Inlet: an inlet region is a surface over which mass enters the flow domain. For each element face on an inlet region, one of the following must be specified:

- fluid speed and direction (either normal to the inflow face or in a particular direction in Cartesian coordinates),
- mass flow rate and flow direction, or
- the total pressure -

$$P_{total} \equiv P + \frac{1}{2}\rho V^2 = P_{total\,spec} \quad (4.1)$$

and flow direction

If the flow is turbulent then it is necessary to specify two properties of the turbulence. Most commonly, the intensity of the turbulence -

$$I \equiv \frac{\text{Average of speed fluctuations}}{\text{Mean speed}} \quad (4.2)$$

and one additional property of the turbulence: the length scale of the turbulence (a representative average size of the turbulent eddies), or eddy viscosity ratio (turbulent to molecular viscosity ratio, μ_t/μ) are specified. Typical turbulence length scales are 5% to 10% of the width of the domain through which the mass flow occurs.

Outlet: an outlet region is a surface over which mass leaves the flow domain. For each element face on an outlet region, one of the following must be specified:

- fluid velocity (speed and direction),
- mass flow rate, or
- static pressure

A specified static pressure value can be set to a specific face, applied as a constant over the outflow region, or treated as the average over the outflow region. No information is required to model the turbulence in the fluid flow at an outflow.

Opening: a region where fluid can enter or leave the flow domain. Pressure and flow direction must be specified for an opening region. If the opening region will have fluid entering/leaving close to normal to the faces (i.e. a window opening) then the specified pressure value is the total pressure on inflow faces and the static pressure on outflow faces (a mixed type of pressure). If the opening region will have fluid flow nearly tangent to the faces (i.e. the far field flow over an airfoil surface) then the specified pressure is a constant static pressure over the faces. For turbulent flows, the turbulence intensity must also be set.

Wall: a solid wall through which no mass can flow. The wall can be stationary, translating (sliding), or rotating. If the flow field is turbulent then the wall can be either smooth or rough. Depending upon which of these options are chosen, suitable values must be input (i.e. the size of the roughness elements).

Symmetry: a region with no mass flow through the faces and with negligible shear stresses (and negligible heat fluxes). This condition is often used to simulate a two-dimensional flow field with a three-dimensional flow solver and to minimize mesh size requirements by taking advantage of natural symmetry planes in the flow domain.

Inlet Sets	Outlet Sets	Solution Predicts
velocity	static pressure	inflow static pressure
total pressure	velocity	outflow pressure inflow velocity
total pressure	static pressure	system mass flow

Table 4.1: Common boundary condition combinations

Since it is crucial that each surface element face have a boundary condition attached to it, CFX-Pre automatically provides a default boundary condition for each domain. Once all boundary surfaces have been attached to explicit boundary conditions, the default boundary condition object is deleted. This allows the user to identify surfaces which still require explicit boundary conditions.

For the flow solver to successfully provide a simulated flow field, the specified boundary conditions should be realizable (i.e. they should correspond to conditions in a laboratory setup). In particular, ensure that the inlet and outlet boundary conditions are consistent and that they take advantage of the known information. Table (4.1) lists several common inlet/outlet condition combinations along with the global flow quantity which is estimated as part of the solution for each combination.

Domain Models

In incompressible flow fields, the actual pressure level does not play any role in establishing the flow field - it is pressure differences which are important. The solver calculates these pressure differences with respect to a reference pressure. Solution fields are in relative pressure terms but absolute pressure (relative pressure plus reference pressure) is used for equation of state calculations.

In turbomachinery applications it is convenient to analyse the flow in a rotating reference frame. In this case, the domain is in a rotating reference frame and its axis of rotation and rotation rate must be specified.

Fluid Models

Heat Transfer Model: options include:

None: no temperature field is computed (not an applicable option for ideal gases),

Isothermal: a constant temperature field is used,

Thermal Energy: a low speed (neglecting kinetic energy effects) form of the enthalpy conservation equation is computed to provide a temperature field, and

Total Energy: a high speed form for conservation of energy including kinetic energy effects is computed.

Turbulence Model: options include:

None: laminar flow simulation,

k-Epsilon: the accepted state-of-the-art turbulence model involves the solution of two transport equations,

Shear Stress Transport: a variant of the k-Epsilon model that provides a higher resolution solution in near wall regions, and

BSL and SSG Reynolds Stress: two variants of second moment closure models that explicitly solve transport equations for all six components of the turbulent stress tensor and that require significantly more computing resources than the two equation variations.

Turbulent Wall Functions: are required to treat the transition to laminar like flow close to solid walls. The wall treatments are tied to the turbulence model choice. The scalable wall function method used with the k-Epsilon turbulence model is a variant of the standard wall function method. The scalable wall function method automatically adjusts the near wall treatment with mesh spacing in the near wall region.

4.2 Initialization

The algebraic equation set that must be solved to find the velocity and pressure at each mesh point is composed of nonlinear equations. All strategies for solving nonlinear equation sets involve iteration which requires an initial guess for all solution variables. For a turbulent flow, sufficient information must be provided so that the following field values can be set (initialized) at each mesh point:

- velocity vector (3 components),
- fluid pressure,
- turbulent kinetic energy, and
- dissipation rate of turbulent kinetic energy.

CFX-Pre provides a default algorithm for calculating initial values based on interpolating boundary condition information into the interior of the domain. This default algorithm is adequate for many simulations.

The initial conditions can significantly impact the efficiency of the iterative solution algorithm. If there are iterative solution difficulties then values or expressions (with CEL) can be used to provide initial conditions that:

- match the initial conditions to the dominant inlet boundary conditions, and
- align the flow roughly with the major flow paths from inlet regions to outlet regions.

4.3 Output Control

For many simulation cases, especially those with a strong emphasis on fluid mechanics, it is necessary to output additional fields to the res output data file. For example, it is often worthwhile to output the turbulent stress fields throughout the flow domain, wall shear stresses on all boundary walls, and gradient operations applied to all primary solution variables.

4.4 Simulation Type

The numerical formulations for steady and transient flows differ slightly. The focus is on steady flow simulations, however transient evolution, with no transient accuracy, is used in the iterative solution algorithm. Each iteration is treated as a step forward in time.

4.5 Solver Control

The numerical methods operation used in the equation set solver are largely fixed. However some aspects of the numerical methods must be explicitly set by the user:

1. the choice of discretization scheme,
2. the time step size for the flow evolution, and
3. the criteria for stopping the iterative process.

The variation of velocity, pressure, etc. between the mesh points (element nodes) has to be approximated to form the discrete equations. These approximations are classified as the *discretization scheme*. The options for discretization scheme that approximate advective transport flows (listed in order of increasing accuracy) are:

- Upwind - a constant profile between nodes,
- Specified Blend Factor - a blend of upwind and high resolution, and
- High Resolution - a linear profile between nodes.

In choosing a discretization scheme, accuracy is obviously an important consideration. Increasing the accuracy of the discretization may slow convergence, sometimes to the extent that the solution algorithm does not converge.

The choice of the timescale used to advance the solution during the iteration process plays a big role in establishing the rate of convergence. The **Timescale Control** ▼ estimates a reasonable timescale based on estimates of the flow length and typical flow velocity obtained from the geometry and boundary conditions. In some cases the default estimates are not appropriate. In these cases good results are usually obtained when the **Timescale Control** ▼

is set to approximately 30% of the average residence time (or cycle time) of a fluid parcel in the flow domain.

The initial guesses for the velocity, pressure, turbulent kinetic energy, and dissipation rate nodal values will not necessarily satisfy the discrete algebraic equations for each node. If the initial nodal values are substituted into the discrete equations there will be an imbalance in each equation which is known as the equation *residual*. As the nodal values change to approach the final solution, the residuals for each nodal equation should decrease.

The iterative algorithm will stop when either the maximum number of iterations is reached or when the convergence criterion is reached (whichever occurs first). The convergence criterion is a convergence goal for either the maximum normalized residuals or the root mean square (RMS) of the normalized residuals. Note that the residuals are normalized to have values near one at the start of the iterative process.

Chapter 5

CFX Solver Manager: Solver Operation

A solver run requires a definition file to define and initialize the run. Table (5.1) shows how `def` and `res` files can be used to define different runs.

Definition File	Initial File	Use
<code>def</code>		Start from simple initial fields
<code>res</code>		Continue solution for further convergence
<code>def</code>	<code>res</code>	Restart from existing solution with new flow model

Table 5.1: Input file combinations

5.1 Monitoring the Solver Run

The solution of the algebraic equation set is the component of the code operation which takes the most computer time. Fortunately, because it operates in a batch mode, it does not take much of the user's time. The operation of the solver should, however, be monitored and facilities are provided for this.

Table (5.2) shows typical solver diagnostic output listing the residual reduction properties for the first few time steps (iterations) of a solver run.

For each field variable equation set, the following information is output each time step:

Rate the convergence rate

$$\text{Rate} = \frac{\text{RMS res. current time step}}{\text{RMS res. previous time step}}$$

which should typically be 0.95 or less,

```

=====
OUTER LOOP ITERATION = 1                      CPU SECONDS = 1.078E+00
-----
|      Equation      | Rate | RMS Res | Max Res | Linear Solution |
+-----+-----+-----+-----+-----+
| U-Mom              | 0.00 | 1.0E-02 | 7.5E-02 | 5.4E-02 OK |
| V-Mom              | 0.00 | 1.1E-02 | 6.7E-02 | 6.4E-02 OK |
| W-Mom              | 0.00 | 0.0E+00 | 0.0E+00 | 0.0E+00 OK |
| P-Mass             | 0.00 | 1.7E-02 | 1.4E-01 | 9.2 3.8E-02 OK |
+-----+-----+-----+-----+-----+
| K-TurbKE           | 0.00 | 9.1E-02 | 6.9E-01 | 5.7 8.9E-05 OK |
| E-Diss.K           | 0.00 | 9.0E-02 | 1.0E+00 | 8.1 2.1E-05 OK |
+-----+-----+-----+-----+-----+
=====
OUTER LOOP ITERATION = 2                      CPU SECONDS = 1.656E+00
-----
|      Equation      | Rate | RMS Res | Max Res | Linear Solution |
+-----+-----+-----+-----+-----+
| U-Mom              | 2.57 | 2.6E-02 | 8.1E-02 | 5.0E-03 OK |
| V-Mom              | 4.12 | 4.5E-02 | 2.7E-01 | 6.3E-03 OK |
| W-Mom              | 0.00 | 0.0E+00 | 0.0E+00 | 0.0E+00 OK |
| P-Mass             | 0.13 | 2.3E-03 | 1.9E-02 | 9.2 8.7E-02 OK |
+-----+-----+-----+-----+-----+
| K-TurbKE           | 0.65 | 5.9E-02 | 6.9E-01 | 5.7 3.4E-04 OK |
| E-Diss.K           | 0.79 | 7.1E-02 | 9.0E-01 | 12.3 3.4E-07 OK |
+-----+-----+-----+-----+-----+

```

Table 5.2: Typical convergence diagnostics

RMS Res the root mean square of the nodal normalized residuals,

Max Res the maximum nodal normalized residual in the flow domain, and

Linear Solution after each equation set is linearized, an estimate of the solution of the resulting linear equation set is obtained and statistics on this solution are reported:

Work Units a measure of the effort required to obtain the solution estimate,

Residual Reduction the amount that the linear solver has reduced the RMS residual of the linear equation set, and

Status an indicator of the linear solver performance:

OK residual reduction criteria met,

ok residual reduction criteria not met but converging,

F solution diverging,

- * residual increased dramatically and solver terminates due to floating point number overflow error.

Some of the above information is also displayed graphically in the monitor window so that the solver execution can be monitored.

When execution is complete the final results are written to the `res` file. In addition, all of the information pertinent to the operation of the solver is output to the out file, including:

- the CPU memory or storage requirements,
- the physical flow model,
- grid summary,
- estimate of the global length, speed, and time scales based on the initial fields,
- the convergence diagnostics,
- the flows¹ of all conserved quantities through the boundary surfaces (these should balance to 0.01% of the maximum fluxes),
- the wall forces and moments (about the global coordinate system origin) caused by pressure and viscous and turbulent stresses,
- information on the residual distributions,
- estimates of the global length, speed, and time scales based on the final fields, and
- the computational time required to obtain the solution.

¹Note that momentum flows include boundary surface forces due to pressure and viscous/turbulent action.

Chapter 6

CFX-Post: Visualization and Analysis of Results

To the typical user of CFD, the generation of the velocity and pressure fields is not the most exciting part. It is the ability to view the flow field that makes CFD such a powerful design tool. CFX-Post has capabilities for visualizing the results in graphics objects, for using calculation tools, and for controlling the post-processing state.

6.1 Conventions

Hybrid/Conservative Fields: For each flow property calculated at a node there are two fields: *hybrid* and *conservative*. At interior nodes the two fields are identical. For nodes on a boundary surface there are two values for every flow property: the value implied by the boundary condition and the average value in the sub-element region around the node. The first value is the hybrid value and the second value is the conservative value. For a node on a solid wall, the hybrid velocity will be zero and the conservative velocity will typically be non-zero.

Pressure:

$$p_{abs} = \underbrace{\left[p' - \beta_{norm} \frac{2}{3} \rho_{ref} k \right]}_{p_{rel}} + p_{ref} + \rho_{ref} \vec{g} \cdot (\vec{r} - \vec{r}_{ref})$$

where:

Absolute Pressure, p_{abs} : is the pressure used for evaluating thermodynamic state properties;

Pressure, p' : is the pressure field shown by CFX;

Relative Pressure, p_{rel} : is the relative pressure (sometimes referred to as the static pressure);

Reference Pressure, p_{ref} : is a reference pressure level set so that pressure changes due to flow ($\nabla p'$) are similar in size to the pressure levels, p' . This ensures that numerical errors due to subtracting two nearly equal numbers are avoided;

Normal Stress Correction Factor, β_{norm} : is 0 by default and may be set to 1 for two equation turbulence models (set expert parameter *pressure value option* to 1).

Reference Density, ρ_{ref} : is the nominal density for an incompressible fluid or flow (used for all flow terms except the buoyancy force term);

Turbulent Kinetic Energy, k : which is the sum of the three turbulent normal stresses;

Gravity Vector, \vec{g} : is the gravitational acceleration vector;

Position Vector, \vec{r} : is the position vector for calculating the change in pressure due to hydrostatic effects;

Reference Position Vector, \vec{r}_{ref} : is the reference position vector where the hydrostatic effects are taken as zero. Note that the absolute pressure at this reference position is not necessarily the reference pressure; and

Buoyancy Source Term, $S_M = (\rho - \rho_{ref})\vec{g}$: is the momentum source term consistent with the definition of p' .

Vector Magnitude/Direction: For a vector field property called VectorName four values are provided: its magnitude, VectorName, its x component, VectorName X, its y component, VectorName Y, and its z component, VectorName Z. The magnitude is always positive while the components have signs.

Normal Vector: is computed for boundary surface faces by the CFX-Solver and points outwards from the flow domain¹. This is the vector field variable listed in the variable selector list.

Mass Flow Direction: is assumed positive if the flow is into the flow domain.

Wall Shear Stress, τ_w , Force: is the stress (force over wall surface area) due to the action of the fluid on the wall surface. The wall shear force is locally tangent to the wall surface face.

Integration with Direction Specification: When calculating an area integral, **Function** ▼ , the integration can be done over the scalar surface area, **Direction** ▼ , or the projected area normal to a coordinate axis. For example, selecting **Direction** ▼ will integrate on the projected $y - z$ plane.

¹Note that the implied direction convention used by CFX-Post to calculate mass flows is opposite to this convention

Yplus, y^+ : is the conventional scaled distance from a wall to the first interior node in turbulent boundary flows:

$$y^+ \equiv \frac{\rho \sqrt{\tau_w / \rho} \Delta n}{\mu}$$

where Δn is the normal distance between the wall and the first interior node. Values are only available on wall boundary surfaces.

Solver Yplus, y^* : is the scaled distance from the wall used by CFX-Solver to estimate the wall shear stress from the local near wall velocity and the universal logarithmic velocity profile in turbulent boundary layer flows. Values are only available on wall boundary surfaces.

6.2 Objects

Three types of objects can be created: geometrical, flow visualization, and viewer augmentations. Geometrical objects include:

Point: a point in the domain. Often used to probe flow properties within the domain;

Line: a straight line between two points on the line. Intermediate points on the line can be set at intersections with mesh faces, referred to as a *cut* line, or uniformly spread along the line, referred to as a *sample* line;

Plane: a flat plane in the domain. Like a line object, a plane object can be either a cut plane or a sample plane;

Isosurface: the surface along which some scalar field property has a constant value;

Polyline: a piecewise continuous straight line between a series of points. The line can be derived from the intersection of a boundary and another geometrical object or as a contour line; and

User Surface: a surface derived in a manner similar to a polyline object.

The definition of each of these objects involves choosing from a range of options for each attribute including: location, line colour, etc. The object edit panels outline the possible options for each attribute of the object. See the on-line help for further information on each of these objects and their generation.

Flow visualization objects allows exploration of the velocity, pressure, temperature fields.

Common flow visualization objects include:

Wireframe: a singleton object automatically created to show the surface mesh on the flow domain. The *edge angle* controls how much of the surface mesh is drawn. An element edge is drawn if the angle between the two adjacent element faces is bigger than the edge angle. For rectangular geometries and

meshes an edge angle of 30° ensures that the outside edges of the domain are drawn and an edge angle of 0° ensures that all mesh edges are drawn;

Contour: lines of a constant scalar value on a specified surface (like elevation lines on a topological map). The appearance of the plot is controlled by the rendering options. For example, with the smooth shading option turned on a fringe plot (areas between contour lines are filled with colour) is drawn and with no shading only the contour lines are drawn;

Vector: the field of vectors in a region;

Streamline: lines that are parallel to the local velocity vectors. Typically streamlines are started on an inlet surface and will extend to an outlet surface; and

Particle Tracks: If particle paths (an advanced feature) were calculated as part of the simulation then these paths can be drawn.

Again, see the on-line help for further information on each of these objects and their generation.

Common **Viewer** augmentation objects include:

Legend: a scale legend to associate property values with colours;

Text: a piece of text;

Clip Plane: a flat plane that is used to reduce the portion of the domain shown in the viewer; and

Instancing Transformation: for repeating views to show full geometries when periodic or symmetry conditions have been used to model a portion of a domain.

6.3 Tools

Common post-processing tools include:

File/Export ...: allows the export of portions of the results in a space-separated tabular form. This is useful for exporting data to programs like Excel for graphing, etc.;

File/Print ...: allows the export and printing of the graphical image in the viewer window. Images saved in encapsulated postscript (eps) or portable network graphics (png) formats can be easily inserted into reports and presentations;

Tools/Function Calculator: is a powerful tool for carrying out a wide range of mathematical calculations including a range of integration and averaging calculations;

Tools/Probe: shows the values of a flow property on a point specified by the mouse cursor in the **Viewer** window;

Insert/Expression: allows the input of CEL expressions. To learn the expression syntax right, mouse click in the **Definition** box within the **Expression Editor** panel to get a list of possible variables, expressions, locators, functions and constants that can be input into a new expression. There are two type of functions: **Functions/CFX- Post** functions for performing operations on scalar fields and **Functions/CEL** functions for conventional mathematical operations; and

Create/Variable: allows the calculation of new field variables. New variables can be defined in terms of defined expressions or by entering new expressions directly into the variable definition. For example, calculating local pressure coefficients based on the maximum speed in the domain, backstep (i.e. $C_p \equiv \frac{(p-p_{ref})}{\frac{1}{2}\rho V_{max}^2}$) can be done with the expression:

```
(Pressure - 0 [Pa]) / (0.5 * Density * maxVal(sqrt(Velocity u^2 + Velocity v^2)) @backstep^2)
```

for a variable called Cp

6.4 Controls

A set of controls can be used to save a particular post-processing setup or *state* so that it can be repeated. This is useful when comparing different simulations to see the impact of a design change on flow properties. Common controls include:

Views: The image size, orientation, perspective, etc. in the **Viewer** window is associated with a Camera viewer (imagine that the user moves a camera around in space to create a two-dimensional image of a three-dimensional object in the camera's viewer). Four views are provided and can be selected in the upper left corner of the viewing window. Right mouse click in a view to see and set camera properties;

Session: Provides a mechanism for recording and saving a series of operations. This is useful for users interested in learning power programming of CFX-Post (see on-line help for more information);

State: Saves all information (views, graphical objects, expressions and variable) in a *cst* state file. Loading a state file will automatically re-generate all views, objects, expressions, and variables from a previous CFX-Post session.

Chapter 7

Frequently Asked Questions

7.1 Where are the ANSYS-CFX tutorial files?

On the Waterloo NEXUS system look in the file:

```
C:\Software\ANSYS Inc\CFX\CFX-10.0\examples
```

for the ANSYS CFX tutorial and demonstration files.

7.2 How to use an existing mesh after modifying the geometry?

In **Meshing** panel select the Geometry entity in the tree outline. From the row of icon commands select **Geometry** ▼ **Update Use Geometry Parameter Values** . The existing mesh design can be generated on the modified geometry. Note that the modified geometry should use existing names for Named Selections.

7.3 How to use an existing CFX-Pre model after modifying the mesh?

In CFX-Pre Outline panel right click on the Mesh entity and select **Reload Mesh Files**. Create a new .def file. Note that the modified mesh should use existing names for Named Selections or Regions.

7.4 How is heat conduction modelled in a single domain?

ANSYS CFX presumes that a CFD calculation is of interest. However, it is possible to get a heat conduction solution for a flow domain even though the setup is not efficient.

- Set up a simple fluid flow model: laminar flow, thermal energy, appropriate thermal wall or symmetry boundary conditions on all surfaces;

- Under the **Domain Initialization** tab select **Initial Conditions** and for **Cartesian Velocity Components** and **Static Pressure** set **Option** ▼ **Automatic with Value** and set all velocity components, U, V, and W, and the relative pressure to zero values;
- Select **Insert/Solver/Expert Parameter** and go the **Model Over-rides** tab on the far right. Select **Select solve fluids** and set **solve fluids** ▼ **f**. Press **OK**; and
- Select a very large physical timescale under Solver Control.

7.5 Why is there only a few point values given when exporting data along a line normal to a wall?

Some variables like wall shear stress are only defined for nodes on boundaries. If attempting to export boundary-only variables and interior field variables along a cut line normal to a wall there will only be output for the boundary nodes. Similarly, if attempting to export boundary-only variables and interior field variables along a sample line normal to a wall there will only be output for sample points within the first element adjacent to the boundary.

7.6 How is a thin guide vane modelled?




Figure 7.1: Mesh blocking and surfaces for modelling a thin guide vane, Surfaces 2.

Thin solid objects like guide vanes are often modelled as thin surfaces with no thickness. These surfaces are created from surfaces that lie on the boundary between two flow domains. Figure 7.1 shows two solid bodies which are joined along the surface pairs labelled 1 - 3. For this simulation surfaces 2 are intended to model a guide vane in the bend. The mesh blocking inferred from the geometry is also shown in the figure.

See CFX-Mesh Help/Geometry/Geometry Requirements/Geometry for Thin Surfaces for information on creating geometry models with thin surfaces, and ANSYS CFX-Pre User's Guide/Boundary Conditions/Basic Settings Tab/Create Thin Surface Partner for details on modelling thin surface.

The simulation for the mesh model shown in Figure 7.1 was created by:

Design Modeler:

- Create two complete sketches for developing Solid 1 and Solid 2;
- Extrude Solid 1 without merging topology and then use **Tools/Freeze** on this solid;
- Extrude Solid 2; and
- Select both solids and use **Tools/Form New Part** to form a single part.

Meshing: Include the middle edges in edge sizing specifications to ensure uniform meshing in both solids.

CFX-Pre:

- Select the thin surface from the Outline mesh tree of one of the solids (this surface will not be named but will be given a number F XX.YY) and rename the surface to GuideVane (or other meaningful name); and
- Insert a boundary condition for the thin surface and select **Create thin surface partner** to put a wall boundary condition on both sides of the surface.